


# ATT 300 and ATE 300 displays configuration

New  
CE







<b>1. Prerequisite</b>	.....	P 1
1.a - Working principle	.....	P 1
1.b - Output signal selection	.....	P 2
<b>2. Modbus parameters</b>	.....	P 3
2.a - Configuration parameters	.....	P 3
2.b - Modbus functions	.....	P 3
2.c - Register access security key	.....	P 3
<b>3. Activation code and access to functions</b>	.....	P 5
<b>4. Display configuration •  F100</b>	.....	P 6
4.a - Transmitter channel for infrared remote control	.....	P 6
4.b - Serial number of the instrument	.....	P 7
4.c - Slave addressing (Modbus)	.....	P 8
<b>5. Unit of measurement selection •  F200</b>	.....	P 8
5.a - Preprogrammed units of measurement	.....	P 8
5.b - Creation of a new unit of measurement	.....	P 9
<b>6. Channels and analogue input configuration •  F100 et F300</b>	.....	P 10
6.a - Input type selection (analogue or digital)	.....	P 10
6.b - Activation / deactivation of a channel	.....	P 12
6.c - Comma position	.....	P 12
6.d - Minimum and maximum settings of analogue input	.....	P 13
6.e - LED meaning	.....	P 14
<b>7. Modbus communication speed •  F100</b>	.....	P 15
<b>8. Error codes</b>	.....	P 15

## 1.a - Working principle

Class 300 display configuration can be made with the remote control and the Modbus system and enables you to configure the analogue inputs, activate the channels.... .

**Principle:** the configuration options are accessed via **folders and sub-folders** (similar to Windows®). Access is made via a **numerical code** (full details in this manual).






### ■ Meaning of remote control keys

- To increment a value or a level
- To decrement a value or a level
- To validate an input
- To cancel an input or to return to the previous step

#### Channel selector


With this selector, you can swap the transmission channel so that it matches with the transmitter reception channel. See page 6 to configure the transmitter reception channel.

**NOTE** The preview screens were made from the ATE 300. But the principle **remains the same** for the ATT 300 configuration.




## 1.b -Input signal selection

Class 300 displays can output either a **voltage** or a **current** signal (see page 10)




**ATT 300**

With the orange on-off switch located between the terminal blocks (when the display is open), you can choose analogue output 0-10V (voltage) or 4-20 mA (current)



**ATE 300**

With the black on-off switch located on the left side of the display, you can choose the analogue input 0-10V (voltage) or 4-20 mA (current)



## 2.a - Configuration parameters

- Communication speed ..... 19200 Bauds
- Data bits ..... 8 bits
- Stop bit ..... 1 bit
- Parity ..... None
- Flow control ..... None
- Transmitter addressing ..... between 1 and 255  
(default address "0" for single ended bus configuration)  
To change the transmitter addressing, see page 7.

## 2.b - Functions


- Register reading ..... Function 03
- Register writing ..... Function 16
- Communication loop test ..... Function 08

## 2.c - Access codes to Registers

- Registers type ..... Signed long integer (32 bits), permuted (LSB, MSB)
- Values - Modbus code:
  - 1438 (channel 1)
  - 1442 (channel 2)
  - 1446 (channel 3)

*Ex. The value sent by the transmitter is 623*
- Values formatting
  - Modbus code: 1440 (channel 1)
  - 1444 (channel 2)
  - 1448 (channel 3)

<i>Units of measurement</i>	
1	m/s
2	fpm
3	m3/h
4	L/s
5	cfm
6	m3/s
7	°C
8	°F
9	%RH
10	PSI
11	Pa
12	mmH <sub>2</sub> O
13	inWg
14	Kpa
15	mmHg
16	mbar
17	g/kg (absolute humid. p)
18	°C (dew temperature Td)
19	°F (dew temperature Td)
20	°C (humid temp. Tw)
21	°F (humid temp. Tw)
22	KJ/Kg (Enthalpy i)



The formatting displayed is 268.

Unit of measurement => 12 (see chart)

Figure(s) after the comma => 1

Sign => positive

---

If the value measured is equal to 623 :

Result => 62,3 mmH<sub>2</sub>O



**Other access codes to different registers are indicated on each function at stage n°2.**  
Shown as this pictogram:



#### **4.a - Canal du capteur pour la télécommande infrarouge**

Vous pouvez changer le numéro de canal du capteur pour la réception du signal de la télécommande infrarouge.

Par défaut, le numéro du canal du capteur est 0.

**Etape 1** Entrer en mode configuration (cf. page 5). Le numéro de dossier affiché correspond au dernier dossier de configuration utilisé.

**Etape 2**   
 Sélectionner le dossier "100" et valider avec .  
Sélectionner le sous-dossier "100" et valider avec .  
Le curseur : descend sur la ligne des choix possibles.

**Etape 3** A l'aide des touches et , sélectionner le numéro du canal (de 00 à 05).  
Valider avec .

**Etape 4** Le curseur > retourne sur la ligne des sous-dossiers.  
appuyer 2 fois sur pour revenir en mode lecture des valeurs.  
appuyer 1 fois sur pour revenir à la sélection d'un autre dossier.  
utiliser et pour choisir un autre sous-dossier du dossier 100.




This step is COMPULSORY for each configuration.

To access the transmitter functions, **and for safety**, you have to first enter a safety code.

- Please check that the transmitter is powered on.
- If the transmitter displays an error code, please see “Errors Code” section on page 13.

## Step 1


Press to get this screen



The first “0” blinks, which means that this column is activated and you can enter data from the keypad.

## Step 2

Enter CODE “0101” with keypad and validate with



The code must be entered from left to right.

To increment a value or a level, press


To decrement a value or a level, press

To validate a value (level) or to validate the code, press

To return to the previous status or to cancel, press

## Step 3

This screen appears:



This screen confirms that the code was correctly entered, and that you can configure the transmitter.



If the code was wrongly entered, the transmitter initializes and returns to the starting display.



Configuration folder number

The transmitter includes 3 folders maximum:

- 100
- 300
- 200

Ex. folder “200” corresponds to configuration of units of measurement. See page 12.

## Step 4


Selection of configuration folder



To select your configuration folder, press to increment 100 or press to decrement 100.

Once the folder is selected, press to validate.

*On the top left of each page of this manual, you can find a reminder of the configuration folder where the function is available.*





8.8.8.

## 4. Display configuration

### 4.a - Transmitter channel for infrared remote control



You can change the channel number for receiving the signal from the infrared remote control.

**NOTE**

By default, the channel number is **0**.

**Step  
1**

Go into the configuration mode (see page 5). The folder number displayed corresponds to the last configuration folder used.

**Step  
2**

Select the folder “**100**” and validate with .

Select the sub-folder “**100**” and validate with .

**Step  
3**

With and keys, select the channel number (from **00** to **09**). Validate with .

**Step  
4**

The cursor > returns to sub-folders line.

- press twice to return to reading mode

- press once to select another folder.

- with and keys, you can choose another sub-folder from the folder 100.

### 4.b- Serial number of the transmitter

**Step  
1**

Go into configuration mode (see page 5). The folder number displayed corresponds to the last configuration folder used.

**Step  
2**

Select the folder “**100**” and validate with .

Select the sub-folder “**101**”

**Step  
3**

The serial number of the transmitter is displayed (on 2 lines on ATE300 and in horizontal scrolling on ATT300).

The cursor > goes to sub-folders line.

- press twice to return to reading mode.

- press once to return to another folder selection.

- with and keys to choose another sub-folder from the folder 100.



8.8.8.

## 4. Display configuration

### 4.c - Slave addressing (Modbus)

**Step  
1**

8.8.8.

Go into configuration mode (see page 5). The folder number displayed corresponds to the last configuration folder used.

**Step  
2**

8.8.8.



Select the folder “100” and validate with .

Select the sub-folder “106” and validate with .

The cursor > goes to available choices.

**Step  
3**

8.8.8.

With and keys, set the slave addressing number (from 1 to 255). Validate with .

**Step  
4**

8.8.8.

The cursor > goes to sub-folders line.

• press twice to return to reading mode.

• press once to return to another folder selection.

• with and keys to choose another sub-folder from the folder 100.



B.B.B.B.

## 5. Selection of unit of measurement

### 5.a - Pre-programmed units of measurement

21 units are preprogrammed in the display, according to several parameters: pressure, temperature, humidity, air velocity and airflow...

Step  
1

E.B.B.B.

Go into configuration mode (see page 5). The folder number displayed corresponds to the last configuration folder used.

Step  
2

Select the folder “200” and validate with .

Channel 1   Channel 2   Channel 3  
200          201          202

Select sub-folder

and validate with .

The cursor > goes to choices line.

Step  
3

With and keys, select the unit of measurement (see chart below). Validate with .

Units of measurement			
0	m/s	11	mmH <sub>2</sub> O
1	fpm	12	inWg
2	m3/h	13	Kpa
3	L/s	14	mmHg
4	cfm	15	mbar
5	m3/s	16	g/kg (absolute humid. $\rho$ )
6	°C	17	°C (dew temperature T <sub>d</sub> )
7	°F	18	°F (dew temperature T <sub>d</sub> )
8	%HR	19	°C (humid temp. T <sub>w</sub> )
9	PSI	20	°F (humid temp. T <sub>w</sub> )
10	Pa	21	KJ/Kg (Enthalpy i)

22 => free unit - see Page xxx

Step  
4

The cursor > returns to sub-folders line.

- press twice to return to reading mode.
- press once to return to another folder selection.
- with and keys to choose another sub-folder from the folder 200.



## 5.b - Creation of a new unit of measurement

If the unit of measurement of the analogue input is not indicated in the preprogrammed units, this function enables you to create a new unit for each channel.

**Step 1**



Go into configuration mode (see page 5). The folder number displayed corresponds to the last configuration folder used.

**Step 2**



Select the folder “200” and validate with .

Selectionner sub-folder

Channel 1 200	Channel 2 201	Channel 3 202
------------------	------------------	------------------

and validate with . The cursor > goes to choices line.



**Step 3**




With and , select 22. Validate with .

You enter in “Issue a new unit of measurement” mode.



**the new unit of measurement has maximum 4 digits.**

- 1 • By default, no digit segment will be activated.  
The first segment (on the first digit top) blinks.



- 2 • Meaning of the remote control keys


Goes to the next segment

Returns to the previous segment

Activates the segment chosen (if it was not activated) or deactivates it (if it was activated). Then goes to next segment.

Goes to next digit or validate a new unit if the fourth digit is selected.

- 3 • Segments sequence



**Step 4**



Once the new unit is created, select the fourth digit and validate with . The cursor > goes to sub-folders line.

- press twice to return to reading mode.

- press once to return to another folder selection.

- with and keys to choose another sub-folder from the folder 200.



## 6.a - Selection of input type

ATT 300 and ATE 300 have 3 analogue inputs (0-10V or 4-20mA), 1 digital input Rs232 type and one digital input RS485 type (Modbus system). Therefore, 2 different inputs are available: **analogue input or digital input**.


### 2 configuration types::

#### 1-Display of values of a measuring system via Analogue inputs and Rs232


Analogue input 0-10V / 4-20mA

Rs485 digital input

Rs232 digital input



or



When you connect a Class 200/300 transmitter via Rs232, you can choose between **2 solutions of connection**, via the analogue inputs:

- 1> class 200/300 transmitter sends **2 values = 1 analogue input** 0-10V / 4-20mA available (**Channel 3**)
- 2> class 200/300 sends **1 value = 2 analogue inputs** 0-10 / 4-20mA available (**Channel 3 + Channel 1 or Channel 2**, according to the Class 200/300 transmitter configuration. See user manual of Class 200).




If you want to use the analogue inputs, you have to first **put the DIP switch** so that it matches with the input signal required (see page 2)



## 6.a - Selection of input type

2- Display of values of a measuring system via **Digital input**




Step  
1



Go into configuration mode (see page 5). The folder number displayed corresponds to the last configuration folder used.

Step  
2



Select folder "104" and validate with .



Step  
3



With keys and , select **00** to activate the analogue inputs and the **RS 232** or **01** to activate the RS485 digital input (then, the analogue inputs and RS 232 are automatically deactivated).

Validate with .

Step  
4



The cursor returns to sub-folders line.

- press twice to return to reading mode.
- press once to return to another folder selection.
- with and keys to choose another sub-folder from the folder 400.



8.8.8.

## 6. Configuring channels and analogue inputs

### 6.b - Activation / Deactivation of a channel

Step  
1

8.8.8.

Go into configuration mode (see page 5). The folder number displayed corresponds to the last configuration folder used.

Step  
2

8.8.8.

Select folder “300” and validate with .

Select sub-folder

Channel 1 300	Channel 2 304	Channel 3 308
------------------	------------------	------------------

and validate with .

The cursor goes to the line of choices.

Step  
3

With keys and , select **01** to activate the channel or **00** to deactivate it.

Validate with .

Step  
4

The cursor > returns to sub-folders line.

- press twice to return to reading mode.
- press once to return to another folder selection.
- with and keys to choose another sub-folder from the folder 400.

### 6.c - Comma position

Step  
1

8.8.8.

Go into configuration mode (see page 5). The folder number displayed corresponds to the last configuration folder used.

Step  
2

8.8.8.

Select subfolder “300” and validate with .

Select sub-folder

Channel 1 301	Channel 2 305	Channel 3 309
------------------	------------------	------------------

and validate with .

The cursor goes to the line of choices available.

Step  
3

With keys and , select

	ATT 300	ATE 300
00	No comma	✓
01	1 figure after the comma	✓
02	2 figures after the comma	✓
03	3 figures after the comma	✗

Ex. : Value of the channel : 745

00 => 745

01 => 74,5

02 => 7,45

03 => 0,745 (ATT300)

Step  
4

The cursor > returns to sub-folders line.

- press twice to return to reading mode.
- press once to return to another folder selection.
- with and keys to choose another sub-folder from the folder 400.



B.B.B.B.

## 6. Configuring channels and analogue inputs

### 6.d - Minimum and maximum settings of analogue input

With this function, you can enter mini and maxi values of analogue input, so that they correspond to the limits of analogue signal (0-10V or 4-20mA).

#### 1> Output minimum

Step  
1

B.B.B.B.

Go into configuration mode (see page 5). The folder number displayed corresponds to the last configuration folder used.

Step  
2

Select folder “300” and validate with .

Channel 1	Channel 2	Channel 3
302	306	310

Select sub-folder

and validate with .

The cursor goes to

the line of choices.

Step  
3

With keys and , enter the value of the minimum limit. Validate with .

Nota : the left column can be either an integer (from 0 to 9) or the negative sign for a negative minimum limit.

Step  
4

The cursor > returns to sub-folders line.

• press twice to return to reading mode.

• press once to return to another folder selection.

• with and keys to choose another sub-folder from the folder 400.

#### 2> Output maximum

Step  
1

B.B.B.B.

Go into configuration mode (see page 5). The folder number displayed corresponds to the last configuration folder used.

Step  
2

Select folder “300” and validate with .

Channel 1	Channel 2	Channel 3
303	307	311

Select sub-folder

and validate with .

The cursor goes to

the line of choices.

Step  
3

With keys and , enter the value of the minimum limit. Validate with .

Nota : the left column can be either an integer (from 0 to 9) or the negative sign for a negative minimum limit.

Step  
4

The cursor > returns to sub-folders line.

• press twice to return to reading mode.

• press once to return to another folder selection.


• with and keys to choose another sub-folder from the folder 400.



## 6.e - Meaning of alarms and color LED

### 6.e.1 - ATT 300

LED




The 3 LED correspond to the channels.

The channel value (displayed by ATT 300) is automatically linked to a LED.

Ex. LED of channel 1 is activated and its value is 130 Pa.

### 6.e.2 - ATE 300



The channels are represented by 2 LED. The channel value (displayed by ATE 300) is automatically linked to 2 LED.

The 2 different channels are identified with a colour code:

- 2 green LED : channel 1
- 2 orange LED : channel 2
- 2 red LED : channel 3



## 7. Modbus communication speed

Step  
1

F.888

Go into configuration mode (see page 5). The folder number displayed corresponds to the last configuration folder used.

Step  
2

F.888  
03

Select folder “100” and validate with .

Select sub-folder “103” and validate with .

Step  
3

03

With keys and , select a communication speed (see chart below). Validate with .



00	2400 bauds	03	19200 bauds (speed by default)
01	4800 bauds	04	38400 bauds
02	9600 bauds	05	115200 bauds

Step  
4


05

The cursor > returns to sub-folders line.

- press twice to return to reading mode.
- press once to return to another folder selection.
- with and keys to choose another sub-folder from the folder 100



## 10. Error codes



### Error code 2

#### Problem :

- No channel activated

#### Solution :

- Activate at least one channel

**Code** **Description** **Available settings**

**100 200** Channel number of the remote control 0 to 9

**101 202** Serial number reading

**102 204** Modbus slave number 1 to 255

**103 206** Modbus communication speed

<b>00</b>	2400 bds	<b>02</b>	9600 bds	<b>04</b>	38400 bds
<b>01</b>	4800 bds	<b>03</b>	19200 bds	<b>05</b>	115200 bds

**104 208** Input type selection

**Code** **Description** **Available settings**

**200 400** Unit of channel 1

**201 402** Unit of channel 2

**202 404** Unit of channel 3

**Units of measurement**

<b>0</b>	m/s	<b>11</b>	mmH <sub>2</sub> O
<b>1</b>	fpm	<b>12</b>	inWg
<b>2</b>	m3/h	<b>13</b>	Kpa
<b>3</b>	L/s	<b>14</b>	mmHg
<b>4</b>	cfm	<b>15</b>	mbar
<b>5</b>	m3/s	<b>16</b>	g/kg (absolute humid.p)
<b>6</b>	°C	<b>17</b>	°C (dew temp. Td)
<b>7</b>	°F	<b>18</b>	°F (dew temp. Td)
<b>8</b>	%HR	<b>19</b>	°C (humid temp. Tw)
<b>9</b>	PSI	<b>20</b>	°F (humid temp. Tw)
<b>10</b>	Pa	<b>21</b>	KJ/Kg (Enthalpy i)

22 => Free unit - see Page 9



## F.300

Code	Modbus xxx	Description	Available settings
300	600	Activation / Deactivation of channel 1	0 or 1
301	602	Position of the comma of channel 1	
302	604	Minimum of analogue input of channel 1	
303	606	Maximum of analogue input of channel 1	
304	608	Activation / Deactivation of channel 2	0 or 1
305	610	Position of the comma of channel 2	
306	612	Minimum of analogue input of channel 2	
307	614	Maximum of analogue input of channel 2	
308	616	Activation / Deactivation of channel 3	0 or 1
309	618	Position of the comma of channel 3	
310	620	Minimum of analogue input of channel 3	
311	622	Maximum of analogue input of channel 3	







**www.kimo.fr**

**EXPORT DEPARTMENT**

Boulevard de Beaubourg - Emerainville - BP 48  
77312 MARNE LA VALLEE CEDEX 2

Tel : + 33.1.60.06.69.25 - Fax : + 33.1.60.06.69.29

