

User manual

Pressure / Temperature / Humidity / Air velocity / Airflow / Sound level

Installation of probe-holders on probes for portable instruments

PROBE-HOLDERS

There are two different probe-holders: the first one is for wireless probes and the second one is for wired probes.





Probe-holder for wireless probes

Probe-holder for wired probes



INSTALLATION OF THE PROBE-HOLDERS

Wireless probe :

- · Place the wireless probe to see the back side (label side).
- Slide the probe-holder through the top of the probe (see **installation 1** photo).
- Place the two lock pines in the two screw holes located on the top of the wireless probe (see **installation 2** photo).
- Insert the slide of the probe-holder into the slot situated on the side of the protective cover (see following page).





> Wired probe

- · Place the wired probe to see the back side (label side).
- Slide the probe-holder through the bottom of the probe (see **installation 1** photo).
- Place the lock pine in the screw hole located on the bottom of the wired probe (see installation 2 photo).
- Insert the slide of the probe-holder into the slot situated on the side of the protective cover.





Slot on the protective cover

www.kimo.fr

EXPORT DEPARTMENT

Tel: + 33.1.60.06.69.25 - Fax: + 33.1.60.06.69.29

